


Find your product and get support



Europe
<https://aoc.com/uk/support>

Россия
<https://aoc.com/ru/support>

Australia
https://au.aoc.com/user_manual

Hong Kong S.A.R.
https://hk.aoc.com/user_manual

中國台灣
https://tw.aoc.com/user_manual

Indonesia
https://id.aoc.com/user_manual

日本
https://jp.aoc.com/user_manual

한국
https://kr.aoc.com/user_manual

Malaysia
https://my.aoc.com/user_manual

Myanmar
https://mm.aoc.com/user_manual

New Zealand
https://nz.aoc.com/user_manual

Philippines
https://ph.aoc.com/user_manual

Singapore
https://sg.aoc.com/user_manual

ประเทศไทย
https://th.aoc.com/user_manual

Việt Nam
https://vn.aoc.com/user_manual

Middle East
https://me.aoc.com/user_manual

South Africa
https://za.aoc.com/user_manual

Brasil
<https://aoc.portaltpv.com.br/>

India
<https://aoc.com/in-en/support>

US
<https://aoc.com/us/support>

Canada
<https://aoc.com/ca-en/support>




Product information for EU/UK Energy




XXXXXXXXXXXX

QUICK START GUIDE





Q27P4U
MONITOR

AOC.COM
©2025 AOC. All rights reserved





***Different according to countries/regions**
Display design may differ from that illustrated


1




2



X4 Wall Mounting: M4*(10+X)mm
(X=Thickness of Wall mount bracket)



3



4

